Elite CUISINE
BY MAXI-MATIC®

# Sandwich Maker

Model ESM-9002k

## Instruction Manual

Before operating your new appliance, please read all instructions carefully and keep for future reference

# IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock do not immerse cord, plug or appliance in water or any other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair, or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. A fire may occur if appliance is covered or touching flammable material, including curtains, draperies, walls, etc., when in operation.
12. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
13. Do not use appliance for other than intended use.
14. Do not attempt to dislodge food when appliance is plugged in
15. Do not place any of the following materials in the unit: Paper, cardboard, plastic and the like.

**SAVE THESE INSTRUCTIONS**

**THIS PRODUCT IS FOR HOUSEHOLD USE ONLY!**

# SHORT CORD PURPOSE

**NOTE:** A short power cord is provided to reduce the risk of personal injury resulting from becoming entangled in or tripping over a longer cord. **Longer power-supply cords or extension cords are available and may be used if care is exercised in their use.**

If an extension cord is used: (1) the marked electrical rating of the extension cord should be at least as great as the electrical rating of the product; (2) the extension cord should be arranged so that it will not drape over the countertop or tabletop where it can unintentionally be pulled on or tripped over by children or pets.

# POLARIZED PLUG

This appliance is equipped with a ***polarized plug*** (one blade is wider than the other), please follow the below instructions:

To reduce the risk of electrical shock, this plug is intended to fit into a polarized outlet only one way. If you are unable to fit the plug into the electrical outlet, try reversing the plug. If the plug still does not fit, contact a qualified electrician. Never use the plug with an extension cord unless the plug can be fully inserted into the extension cord. Do not alter the plug of the product or any extension cord being used with this product. Do not attempt to defeat the safety purpose of the polarized plug.

# CARE & CLEANING

- Clean the unit only after you have unplugged it for 2 – 3 hours.
- Wipe the inside of the unit with a paper towel.
- Next, wipe the non-stick cooking surface with a damp wet cloth, which can have a little soapy water on it.
- Wipe the exterior of the sandwich maker with a damp cloth.
- **Do not clean the interior / exterior with a scouring pad, abrasive or steel wool as this will damage the finish.**
- **Do not immerse the unit or plug in water or any other liquid.**

# FEATURES

In order to enjoy the features of your new Sandwich Maker please take a few moments to go over these important features. It will help you understand and utilize your cooker to its full cooking potential.

**Non-Stick Cooking Plates:** Two surfaces to allow cooking on both sides of foods simultaneously. Saves time and easy clean up.

**Cook / Stand-by Indicator Light:** Assists in giving you controlled cooking over your sandwiches.

**Compact Storage:** Unit folds up for easy storage. Convenient and takes up less space

**Cool-Touch Exterior:** A cool touch handle and exterior casing provides convenient handling of unit.

# OPERATING INSTRUCTIONS

1) When using for the first time, wipe the surface of the cooking plates with a damp cloth and dry.
   **Note:** First use will burn off the manufacture protective coating. This may cause slight smoking from unit. It is not harmful and will stop after first use.
2) Season the plates with butter or margarine if desired.
3) Plug the unit into an electrical outlet. The RED Stand-By light will turn on.
4) Close the sandwich maker and prepare desired sandwiches while the unit is heating up.
5) When the sandwich maker's thermostat has reached the right temperature, the GREEN cook light will go on.
6) Open the top of the sandwich maker, place slice of bread onto the bottom plate.
7) Fill with desired sandwich condiments. Lay top layer of bread over the top of filling.
8) Close the top lid of the sandwich maker; do not force shut. Steam will eject from between the sandwich maker so please ensure that fingers do not contact with steam.
   **Note:** During toasting and process of making the sandwiches, the GREEN cook light will periodically turn on and off to maintain the right temperature.
9) Your sandwich will be toasted in 2-3 min. Or longer to suit your taste.
10) Open the sandwich maker and remove sandwiches using a plastic or wooden spatula. **NEVER** use metal or sharp utensils to remove food as they may scratch or damage the non-stick surface.
11) Close the top of sandwich maker to preserve the heat until ready to toast the next sandwiches.
12) Unplug unit when finish using.

**For Best Results:**

- Always preheat the sandwich maker before use. Plug cord into a power outlet while preparing the fillings.
- For soft or liquid sandwich fillings, use medium sliced bread.
- Flavored butter or margarine can also be used.
- A teaspoon of sugar sprinkled on the outside of bread slices makes the toasted sandwiches crispier; especially for fruit filled sandwiches.

# RECIPES

## Tomato & Bacon Sandwiches

*Ingredients*:

- 2 strips bacon
- 1 tomato; chopped
- 1 Teaspoon chopped parsley
- 2 slices of bread

Fry bacon in a fry pan until cooked. Remove bacon and slice into thin pieces. Combine with chopped tomatoes and parsley.
Place filling onto bread in sandwich maker. Close unit and cook until golden brown.

*Makes 2 Triangular Sandwiches.*

---

## Banana Sandwiches

*Ingredients:*

- 4 slices of bread
- 1 banana; peeled
- 1-2 Teaspoons of brown sugar

Slice banana into thin slices. Place slices evenly onto bread pieces inside the sandwich maker. Sprinkle brown sugar onto the bananas. Place top piece of bread over the filling.
Close unit and cook until golden brown.

*Makes 4 Triangular Sandwiches.*

---

## Ham & Pineapple Sandwiches

*Ingredients:*

- 2 slices of ham; chopped
- 2 slices of cheddar cheese
- 2 Tablespoons diced pineapples
- 4 slices of bread

Combine ham and pineapples and mix together. Fill bread slices on sandwich maker. Place slice of cheese on each sandwich set. Lay top piece of bread over the filling. Close unit and cook *Makes 4 Triangular Sandwiches.*

# RECIPES (CONT.)

## Apple Turnovers

*Ingredients:*

2 Tablespoons stewed apples
or canned pie-apples
4 slices of bread / raisin bread
Optional: 1-Tablespoon raisins
1 Teaspoon castor sugar
1 Teaspoon cinnamon

Place filling onto bread in sandwich maker. Sprinkle with sugar and cinnamon. Put top layer of bread over the filling. Close unit and cook until golden brown.
*Makes 4 Triangular Sandwiches.*

---

## Tomato Grilled Cheese

*Ingredients:*

4 Slices of Bread
2 Slices of Cheddar Cheese
1 Tablespoon of Chopped Parsley
4 Slices of Tomato
2 Slices of Mozzarella Cheese

Place slices of bread onto sandwich maker. Put 2 slices of tomatoes on each piece of bread. Put one slice of each cheese onto of tomato slices. Sprinkle with chopped parsley. Put top layer of bread over the sandwich. Close unit and cook until golden brown or until cheese melts thoroughly.
*Makes 4 Triangular Sandwiches.*

---

## Indian Curry Chicken

*Ingredients:*

1 Cup minced chicken
1 Teaspoon onion; chopped
1 Teaspoon curry powder
4 Tablespoons of tomato; chopped
1 Teaspoon Worcestershire sauce
1/2 Teaspoon butter

Melt butter in fry pan and stir in all ingredients. Cook for 4-5 minutes on medium heat.
Place slices of bread onto sandwich maker. Fill with the cooked chicken mixture. Put top layer of bread over the sandwich. Close unit and cook until golden brown. *Makes 4 Triangular Sandwiches.*

## LIMITED WARRANTY* ONE (1) YEAR
## WARRANTY IS ONLY VALID WITH A DATED PROOF OF PURCHASE

1. Your small kitchen appliance is built with precision, inspected and tested before leaving our factory.

2. It is warranted, to the original purchaser to be free from any manufacturing defects under normal use and conditions for one (1) year, cord excluded. This Warranty applies only to the original purchaser of this product.

3. If you need to exchange the unit, please return it in its original carton, with a sales receipt, to the store where you purchased it. If you are past the stores allowed return policy period, please see the enclosed Warranty.

4. If you use your appliance for household use and according to instructions, it should give you years of satisfactory service.

5. During the one-year warranty period, a product with a defect will be either repaired or replaced with a new or reconditioned comparable model (at our option) when the product is returned to our Service Center. (See the "Returns" section below).

6. The repaired or replacement product will be in warranty for the remaining balance of the one-year warranty period and an additional one-month period.

7. **This limited warranty covers appliances purchased and used within the 50 contiguous states plus the District of Columbia and does NOT cover:**
- Damages caused by unreasonable use, neglect, normal wear and tear, commercial use, improper assembly or installation of product.
- Damages caused in shipping.
- Damages caused by replacement or resetting of house fuses or circuit breakers.
- Defects other than manufacturing defects.
- Breakage caused by misuse, abuse, accident, alteration, lack of proper care and maintenance, or incorrect current or voltage.
- Lost or missing parts of the product. Parts will need to be purchased separately.
- Damages of parts that are not electrical; for example: cracked or broken plastic or glass.
- Damage from service or repair by unauthorized personnel.
- Extended warranties purchased via a separate company or reseller.
- Consumer's remorse is not an acceptable reason to return a product to our Service Center.

*One Year Limited Warranty valid only in the **50 contiguous states plus the District of Columbia, excluding** Puerto Rico and the Virgin Islands.
This warranty is effective only if the product is purchased and operated in the USA; product usage which is in violation of the written instructions provided with the unit will void this warranty.
For international warranty, please contact the local distributor.
**Any instruction or policy included in this manual may be subject to change at any time.

***MAXI-MATIC, USA***
18401 E. Arenth Ave. City of Industry, CA 91748
Customer Service Dept: (626) 912-9877 Ext: 120/107 MON-FRI 8am-5pm PST
Website: www.maxi-matic.com email: info@maxi-matic.com

## RETURN INSTRUCTIONS

**RETURNS:**

A. Any return of defective merchandise to the manufacturer must be processed accordingly by first contacting customer service (contact information shown below) to obtain an RA # (Return Authorization Number). We will not accept any returns of merchandise without an applicable RA #.

B. IMPORTANT RETURN INSTRUCTIONS. Your Warranty depends on your following these instructions if you are returning the unit to Maxi-Matic USA:

1. Carefully pack the item in its original carton or other suitable box to avoid damage in shipping.
2. Before packing your unit for return, be sure to enclose:
   a) Your name, full address with zip code, daytime telephone number, and RA#,
   b) A dated sales receipt or PROOF OF PURCHASE,
   c) The model number of the unit and the problem you are having (Enclose in an envelope and tape directly to the unit before the box is sealed,) and
   d) Any parts or accessories related to the problem.
3. Maxi-Matic USA recommends you ship the package U.P.S ground service for tracking purposes. We cannot assume responsibility for lost or damaged products returned to us during incoming shipment. For your protection, always carefully package the product for shipment and insure it with the carrier. C.O.D shipments cannot be accepted.
4. **All return shipping charges must be prepaid by you.**
5. Mark the outside of your package:
   MAXI-MATIC USA
   18401 E. ARENTH AVE.
   CITY OF INDUSTRY, CA 91748
6. Once your return has been received by our warehouse, Maxi-Matic USA will repair or replace the product if it is defective in material or workmanship, subject to the conditions in paragraph B.
7. **Maxi-Matic will pay the shipping charges to ship the repaired or replacement product back to you.**

# Importantes medidas de seguridad

Cuando use aparatos eléctricos, precauciones básicas de seguridad deberán seguirse, incluyendo las siguientes.

1. Lea todas las instrucciones cuidadosamente, antes de usar el aparato
2. No toque las superficies calientes, use el mango o las agarraderas.
3. Remueva todo material de empaque, antes de usar el aparato
4. Lave todas las partes o accesorios removibles, antes de usar por vez primera.
5. Para protegerse, de una descarga eléctrica, no sumerja el cordón, conector o aparato en agua o ningún otro líquido.
6. Cercana supervisión es necesaria, cuando el aparato sea usado por o cerca de niños
7. Desconecte el aparato, cuando no esté en uso y antes de limpiarlo. Permita que se enfríe, para remover las partes o accesorios.
8. Nunca use ningún aparato con el cordón dañado, enchufe, mal funcionamiento o dañado en alguna otra forma.
9. El uso de accesorios no recomendados por el fabricante, pueden causar daños personales o al aparato.
10. No lo use a la intemperie o en lugares húmedos.
11. No deje que el cordón cuelgue de la orilla de la mesa, mostrador o toque cualquier superficie caliente.
12. No lo ponga sobre o cerca de superficies calientes como estufas y hornos
13. Siempre deberá conectar el cordón eléctrico al aparato y después al toma corriente eléctrica, si aplica.
14. Siempre deberá de apagar el aparato antes de desconectar del toma corriente.
15. Nunca introduzca alimentos muy grandes o utensilios de metal en el aparato, podría causar fuego, descarga eléctrica o daños personales
16. Fuego podría ocurrir, si el aparato es cubierto o toca material inflamable como cortinas alfombras y paredes cuando esté en uso.
17. Extrema precaución deberá tener cuando use depósitos construidos de otro material que no sean de metal o vidrio, si aplica.
18. No guarde ni ponga ningún material dentro del aparato, únicamente los accesorios recomendados por el fabricante, cuando no esté en uso.
19. No ponga dentro o en la superficie exterior del aparato los siguientes materiales, papel, cartón, plásticos o algún otro material parecido.
20. PRECAUCION. Par evitar daños a la superficie de sus muebles. Algunas superficies de mesas o mostradores hechos y recubiertos de laminado de CORIAN, MADERA FINA O FORMICA. No están diseñados para soportar calores prolongados generados por ciertos aparatos eléctricos de cocina.

**GUARDE ESTAS INSTRUCCIONES**

## ESTE PRODUCTO ES PARA USO DOMÉSTICO UNICAMENTE.

# Limpieza y cuidados

- Limpie la unidad después de haberla desconectado del toma corriente y espere a que enfríe.
- Limpie por dentro de la unidad con toallas de papel.
- Enseguida limpie las cavidades de la sandwichera con un trapo húmedo y jabonoso.
- Limpie el exterior de la sandwichera con un trapo húmedo .
- **No limpie el interior o exterior de la sandwichera con estropajos de metal o limpiadores abrasivos, ya que estos podrían dañar el acabado de la sandwichera**
- **No sumerja la sandwichera en agua.**

# Propósito del cordón corto

1) Se incluye un cordón eléctrico corto con el Propósito de reducir riesgos de lastimarse usted mismo ya que podría tropezarse con el.
2) Extensiones eléctricas pueden usarse .
3) Si va a usar un cordón mas largo, tenga en consideración lo siguiente:

   La extensión eléctrica a utilizar deberá ser igual o de mas amperaje que las especificaciones eléctricas de la sandwichera.
   La extensión eléctrica deberá de acomodarse de tal manera de que no cuelgue del lugar donde tiene colocada la sandwichera o que esta pueda ser jalada por niños o que se puedan tropezar.

# Enchufe polarizado

**Esta sandwichera tiene un enchufe polarizado.** Significa que una de las dos navajas que componen el enchufe es mas ancho que el otro, favor de seguir las siguientes recomendaciones:
**Para reducir el riesgo de una descarga eléctrica**. Este enchufe solo se conecta de una manera en la toma de corriente eléctrica , si el enchufe no entra en el receptáculo invierta el enchufe, y si aún no entra en el receptáculo ,contacte a un electricista calificado. No intente modificar el enchufe de ninguna manera.

***ESTE APARATO ES PARA USO DOMESTICO UNICAMENTE***

# CARACTERISTICAS

De manera que conozca usted las características de su nueva sandwichera, favor de de leer estas importantes características, el cual le ayudara a entender y utilizar su aparato al máximo.

**Superficie para cocinar con antiadherente:** Dos superficies antiadherentes con ocho cavidades para dos sándwiches que le permitirán cocinar simultáneamente por ambos lados. Le ahorrara tiempo y es muy fácil de limpiar.

**Luces indicadoras de espera/ cocinado:** Le da control sobre el cocinado de sus sándwiches.

**Almacenado compacto:** La unidad se dobla para su fácil guardado, es conveniente y toma poco espacio

**Superficie exterior de tacto frío:** Le permite un conveniente manejo de la unidad

# Como Usarla

13) Cuando use la sandwichera por vez primera, limpie la superficies de los platos de cocinar con un trapo húmedo y luego seque perfectamente. **Nota**: Al primer uso quemara la capa protectora de fabricación, esto causará un ligero humo en la sandwichera, **esto no es peligroso** y se quitara después del primer uso.
14) Si lo desea, unte los platos con mantequilla o margarina.
15) Conecte su sandwichera al toma corriente eléctrica, la luz verde de cocinar y la roja de espera se encenderán.
16) Cierre la sandwichera, y mientras esta se calienta, prepare los sándwiches que va a cocinar
17) Cuando el termostato de la sandwichera alcance la temperatura ideal, la luz verde de cocinar se apagará.
18) Ponga los condimentos deseados en el pan y luego ponga otro pedazo de pan encima
19) Abra la sandwichera y coloque de 2 a 4 rebanadas de pan en la plancha inferior de la sandwichera
20) Cierre la sandwichera, al estar cocinando va a salir vapor, así que tenga cuidado de que sus manos no entren en contacto con el vapor
21) **Nota**: Durante el proceso de hacer sus sándwiches, la luz verde periódicamente se va a encender y apagar esto es normal y es para mantener la temperatura correcta
22) Sus sándwiches estarán listos en 2 o 3 minutos, de un poco mas de tiempo si le gustan mas tostados.
23) Abra la sandwichera y saque los sándwiches usando una espátula de plástico o de madera
24) Cierre la sandwichera para mantener el calor hasta que este listo para hacer los demás sándwiches
25) Desconecte la sandwichera del toma corriente eléctrica cuando termine de usarla

**GARANTÍA LIMITADA * UN (1) AÑO**
**GARANTIA ES VALIDA CON UNA PRUEBA DE COMPRA FECHADA**

1. Su aparato de cocina está construido con precisión, inspeccionados y probados antes de salir de nuestra fábrica.

2. Se garantiza, al comprador original, de estar libres de defectos de fabricación en condiciones de uso normales y las condiciones para un (1) año, cordones excluidos. Esta garantía se aplica sólo al comprador original de este producto.

3. Si necesita cambiar la unidad, devuélvala en su caja original, con el recibo de compra, a la tienda donde lo compró. Si usted está más allá del plazo concedido para el retorno por la política de la tienda, por favor consulte la garantía incluida.

4. Si utiliza el aparato para uso doméstico y de acuerdo con las instrucciones, debería ofrecerle años de servicio satisfactorio.

5. Durante el período de garantía de un año, un producto con un defecto será reparado o reemplazado por un modelo nuevo o reacondicionado (a nuestro criterio) cuando el producto sea devuelto a nuestro Centro de Servicio. (Consulte la sección "Devoluciones" a continuación).

6. El producto reparado o reemplazado estará garantizado por el saldo restante del período de garantía de un año y un plazo adicional de un mes.

**7. Esta garantía limitada cubre los aparatos comprados y usados en los 50 estados contiguos y el Distrito de Columbia, y no cubre:**
- Los daños causados por el uso excesivo, negligencia, uso y desgaste normal, uso comercial, montaje o instalación incorrecta del producto.
- Los daños causados durante el envío.
- Los daños causados por la sustitución o reposición de fusibles o disyuntores.
- Defectos que no sean defectos de fabricación.
- Rotura causada por mal uso, abuso, accidente, alteración, falta de cuidado y mantenimiento, o incorrecta de corriente o voltaje.
- Pérdida o falta alguna pieza del producto. Las piezas se deben comprar por separado.
- Daños de piezas que no sean eléctricos; por ejemplo: agrietado o roto de plástico o de vidrio.
- Daños por servicio o reparación por personal no autorizado.
- Las garantías extendidas compradas a través de una empresa independiente o revendedor.
- Remordimiento del consumidor no es una razón aceptable para devolver un producto a nuestro Centro de Servicio.

* Un año de garantía limitada válida solamente en los 50 **estados contiguos y el Distrito de Columbia, excluyendo Puerto Rico y las Islas Vírgenes.**
Esta garantía es válida sólo si el producto es comprado y operado en los EE.UU., el uso del producto que se encuentra en violación de las instrucciones escritas proporcionadas con la unidad anulará esta garantía.
Para la garantía internacional, por favor póngase en contacto con el distribuidor local.
** Cualquier instrucción o política incluida en este manual puede estar sujeta a cambios en cualquier momento.

***MAXI-MATIC, EE.UU.***
18401 E. Ave Arenth. City of Industry, CA 91748
Departamento de Atención al Cliente: (626) 912-9877 Ext: 120/107 Lunes a viernes 8am-5pm PST
Sitio web: www.maxi-matic.com email: info@maxi-matic.com

## INSTRUCCIONES DE DEVOLUCIÓN

**DEVOLUCIONES:**

A. Cualquier devolución de mercancía defectuosa al fabricante deben ser procesados apropiadamente contactando primero al servicio al cliente (información de contacto se muestra a continuación) para obtener un # RA (Número de autorización de devolución). No se aceptará ninguna devolución de mercancía sin un # RA aplicable.

B. INSTRUCCIONES IMPORTANTES DE RETORNO. Su garantía depende que usted siga estas instrucciones si va a devolver la unidad a Maxi-Matic EE.UU.:

1. Empaque cuidadosamente el producto en su caja original o en otra caja adecuada para evitar daños durante el envío.
2. Antes del envío de la devolución unidad, asegúrese de adjuntar:
   a) Su nombre, dirección completa con código postal, número de teléfono durante el día, y #RA
   b) Un recibo de compra fechado o COMPROBANTE DE COMPRA,
   c) El número de modelo de la unidad y el problema que tiene (Encierre en un sobre y pegue directamente a la unidad antes de sellar la caja) y
   d) Todas las piezas o accesorios relacionados con el problema.
3. Maxi-Matic EE.UU. recomienda enviar el paquete de servicio terrestre de UPS para fines de seguimiento. No podemos asumir la responsabilidad por productos perdidos o dañados devueltos a nosotros durante el transporte entrante. Para su protección, siempre cuidadosamente empaquetar el producto para su envío y asegurarlo con la compañía. Envíos C.O.D no puede ser aceptado.
4. **Todos los gastos de envío de devolución debe ser pagado por usted.**
5. Marque el exterior del paquete:
   MAXI-MATIC EE.UU.
   18401 E. ARENTH AVE.
   CITY OF INDUSTRY, CA 91748
6. Una vez que su devolucion ha sido recibida por nuestro almacén, Maxi-Matic EE.UU. se compromete a reparar o sustituir el producto si presenta defectos de materiales o mano de obra, sujeto a las condiciones del apartado B.
7. **Maxi-Matic pagará los gastos de envío para enviar el producto reparado o reemplazado de nuevo a usted.**